


Steam Humidifier SKE series



Installation instruction
& user manual

READ AND SAVE THESE INSTRUCTIONS



Foreword

1. These installation instructions and operation manual have been developed to facilitate the installation and the operation of the SKE series steam humidifier.
The strict application of these instructions will ensure the conformity of your installation and operation as per manufacturer's recommendations.
2. The application of these instructions is one of the conditions for the application of the warranty.
3. The application of these instructions does not ensure at any time conformity to procedures, regulation or local codes, regarding electric installation and connection to local water supply.
4. This product has been declared to conform to applicable European safety and electromagnetic compatibility standards and directives and bear the CE mark. The certificate of conformity CE is available upon request to the manufacturer.
5. © 2011: All right reserved, this document cannot be reproduced totally or partially by any mean whether, electronic, mechanical, photocopy, recording or other, without prior written authorization of National Environmental Products Ltd.

Manufacturer Presentation

National Environmental Products Ltd. (NEP) is the owner of the brand Neptronic®.
NEP develops, manufactures and services a complete line of:

- Steam humidifiers,
- Humidistat among the most precise and the most reliable on the market.
- Actuators to regulate air damper or valves
- Electric heaters
- Thermostats and other control peripherals used to control HVAC equipment.

For more information about our products, visit our web site at www.neptronic.com

Each Neptronic® product benefits from over 25 years of experience of our qualified staff.
From the inspiration to realization, innovation has been the standard in design. As the result of this dedication, NEP Ltd. owns several patents, notably the ENERDRIVE system and the AFEC system.
Manufacturing is conducted on the premises of our modern 7 000m² facility in Montreal, Canada.
Our quality system is built on the ISO 9001 model.

Our vision "**Customer for Life**" is realized by listening their needs and by supplying them with products, which exceed their expectations in quality, functionality and durability.

National Environmental Products Ltd.

Tel. (Toll free): 1 800 361-2308

Tel.: (1) (514) 333-1433

Fax: (1) (514) 333-3163

Fax Customer service: (514) 333-1091

Business hours: from Monday to Friday, 8:00am to 5:00pm (Eastern time)



Table of content

Foreword & Manufacturer presentation	i
1. Presentation.....	2
1.1. Overview	2
1.2. Definition	3
2. Characteristics	4
3. Mechanical installation.....	5
3.1. General recommendations	5
3.2. Positioning	5
3.3. Wall mounting	5
4. Steam dispersion system selection and positioning	6
4.1. Steam dispersion system selection	6
4.2. Positioning of S.A.M or S.A.M.E2	8
5. Steam output connection	11
5.1. Typical installation	11
5.2. General recommendations	11
5.3. Installation of "S" traps on the steam line	11
5.4. Position of steam output	12
5.5. Installation of humidifier with Space Distribution Unit (SDU).....	13
6. Plumbing connection.....	14
6.1. Water supply	14
6.2. Drain connection	15
7. Power supply connections.....	15
8. Low voltage control connections	16
8.1. "ON/OFF" Humidifier	16
8.2. Modulating Humidifier	16
8.3. Common Alarm Connections.....	20
8.4. Controls Placement (steam dispersed into a duct or AHU)	20
9. Front panel display features	21
9.1. Description display modes	22
9.2. Programming	24
10. Control p.c. board.....	25
10.1. Main p.c. board	25
10.2. Modulating p.c. board	25
11. Start up procedure.....	26
12. Service	27
12.1. General	27
12.2. Evaporation chamber cleaning	27
13. Exploded view & Bill of Material.....	30
13.1. Exploded view	30
13.2. Bill of Material	31
14. Trouble shouting guide.....	33
General condition of sale & warranty	37



1. Presentation


Thank you for your confidence in Neptonic® product. You have purchased the best and the most robust humidifier for its category.

1.1. Overview

1.1.1. List of accessories supplied

- 2 sets of keys.
- 2 adjustable collars for the connection of the steam hose for each steam output.
- 1 female compression fitting $\frac{3}{4}$ hydraulic for the drain output of the evaporation chamber.
- 1 female compression fitting $\frac{1}{2}$ hydraulic for the drain output of the drip pan.
- 1 female fitting for the water supply connection.
- 1 Installation instruction and operation manual.

1.1.2. Overview of the Humidifier





1.1.3. Options available

The following options are available when purchasing a SKE humidifier:

- Modulating control humidifier – suffix M (i.e. SKE20**M**)
- Humidifier for system supplied with Deionised water or Reverse Osmosis water, dissolved solids more than 1 ppm (SF DI-APPLICATION)
- Humidifier for system supplied with Deionised water or Reverse Osmosis water, dissolved solids more than 0.028 ppm (SF ULTRAPURE-DI)
- Space Distribution Unit mounted on humidifier (SDU) or remote installation (SDU-REM)
- Network communication system, BACnet – suffix B (i.e. SKE20M-400-3**B**)
- Stainless steel humidifier cabinet – suffix P (i.e. SKE20M-400-3**P**)
- Dry contact to activate an external fan relay on a call for humidity (SF SK300FANRELAY)

1.2. Definition

1.2.1. Evaporation chamber

Assembly including the metal cylinder and a cover equipped with one or several heater elements. It is the heart of the humidifier, which produce steam.

1.2.2. SDU (Space Distribution Unit)

Integrated steam distribution unit, optional on certain humidifiers.

1.2.3. Multi-Steam system

Custom made system of steam distribution. This system is designed to allow very short absorption distances (less than 900mm).

1.2.4. S.A.M. (Steam Absorption Manifold)


Steam manifold adapted to air duct size to allow steam absorption in relatively short distance (less than 1500mm).

1.2.5. S.A.M.E2 (Steam Absorption Manifold with 2 Eyelets)

Steam manifold with two eyelets adapted to application with restricted air duct dimensions to allow steam absorption in relatively short distance (less than 1500mm).



2. Characteristics



Model	Steam	Consumption			Output		Dimension of the cabinet (mm)						Option SDU
	Capacity (Kg/Hr)	Power (KW)	Current (A)		Qty	Diam (mm)	Size	A	B	C	D	E	
			230V 1 phase	400 V 3 Phases									
SKE05	5	3,7	16	5,5	1	35	Small	597	470	292	140	737	SDU-1
SKE10	10	7,5	33	11	1	35	Medium	724	533	318	165	890	SDU-2
SKE20	20	15	-	22	1	35	Medium	724	533	318	165	890	SDU-2
SKE30	30	22	-	33	2	35	Medium	724	533	318	324	1048	SDU-3
SKE40	40	30	-	44	2	35	Medium	724	533	318	324	1048	SDU-3
SKE50	50	36	-	53	2	54	Large	794	813	318	-	-	-
SKE60	60	44	-	64	2	54	Large	794	813	318	-	-	-
SKE80	80	60	-	87	3	54	Large	794	813	318	-	-	-

Options:

- On modulating humidifier, the maximum steam output can be programmed with the function "LOCK ON" in Program mode.

WARNING (MODULATING HUMIDIFIER): THE MAXIMUM POWER OF THE ELECTRICAL INSTALLATION SHOULD BE IN ACCORDANCE WITH THE ABOVE TABLE, DO NOT TAKE ACCOUNT A POSSIBLE REDUCTION OF STEAM OUTPUT, DUE TO MODULATION.




3. Mechanical installation

3.1. General recommendations

- **CAUTION:** RISK OF ELECTRIC SHOCK. DISCONNECT THE APPLIANCE FROM THE ELECTRIC SUPPLY BEFORE TO PROCEED TO INSTALLATION.
- Location: Plan a location easy to access in order to permit an easy inspection and servicing of the humidifier.
Do not install humidifier where failure of the appliance could cause damage to the building structure or to costly equipment.
This location should be well ventilated; the ambient temperature should not exceed 30°C.
- The maximum distance between the humidifier and the ventilation duct should not exceed 5 meter (maximum length of the steam hose).

3.2. Positioning


- The front panel and the right side (electrical compartment) should be accessible in order to permit the servicing.
Leave a clearance of at least 1,25m to the front panel and 0,6m to the right side.
- The humidifier should be mounted at a minimum of 1m to 1,2m above floor level.
Leave a clearance of at least 0,25m under the humidifier for installation of water supply, drain piping and electrical connections.



Positioning (Illus. 3)

3.3. Wall mounting

- Use the keyholes located on the back panel of the humidifier.
- Before to proceed to the wall mounting, take off the Evaporation chamber sub assembly (see section 12, Servicing).
- Check the solidity of the chosen support or wall (bricks, concrete, stud partition wall, etc) on which the humidifier will be mounted.
- Drill holes for the upper anchors (holes with eyelet) into the support or wall as per dimensions specified in the table (illus.4).
The holes dimensions (diameter and depth) should be in accordance with the recommendations of the chosen anchors.
- Install then bolt anchors, if required.
- Screw-on the 2 or 3 upper screws (holes with eyelet) of a minimum diameter of #10 (6mm) (screws are not supplied).
Leave a clearance between head screws and wall in order to permit the mounting of the humidifier.
- Use the keyholes located on the back panel of the humidifier.
- Hang on the humidifier to the 2 or 3 screws; it is preferable let the front door open during this operation.
According to the size and weight of the humidifier, you may need the help of a second person to assist you.
- When the humidifier is positioned on the upper screws, tighten the screws to secure the humidifier.
- If applicable, install and secure lower screws.



Front view (Illus. 4)


Model	Dimensions mm						
	A	B	C	D	E	F	G
SKE05	-	202	165	516	-	-	-
SKE10, SKE20, SKE30, SKE40	-	254	203	625	276	203	254
SKE50, SKE60, SKE80	102	305	265	698	276	576	-

4. Steam dispersion system selection and positioning

4.1. Steam dispersion system selection

In order to prevent the accumulation of condensation in air ducts, NEP has designed 4 basic configurations of steam distribution to provide the client with the most economical solution for any particular application.


4.1.1. S.A.M. (steam absorption manifold) Horizontal duct



The SAM is to be installed where absorption distances are short, less than 1500mm, and/or low duct temperatures are in effect.

(*Illus. 5*)

4.1.2. S.A.M.E2 (steam absorption manifold) Horizontal duct




The SAME2 is to be installed where absorption distances are short, less than 1500mm and/or low duct temperatures are in effect. SAME2 are used in applications with restricted duct dimensions.

(*Illus. 6*)




4.1.3. S.A.M. or S.A.M.E2 (steam absorption manifold) Vertical duct



SAM or SAME2 for vertical ducts are used where the absorption distances are normal and the client requires an economical as well as an efficient solution.

4.1.4. Multi-Steam system



The Multi-Steam system is to be installed in critical locations in air handling systems, particularly where absorption distances are very short, less than 900mm, or low air duct temperatures are in effect.

The Multi-Steam is custom made to the dimensions of duct or AHU.

Instructions to install Multi-Steam system are described in a specific installation instructions manual enclosed with the Multi-Steam system.



4.2. Positioning of S.A.M or S.A.M.E2

4.2.1. Duct mounting


Steam manifold should be mounted and secured through the side of the air handling unit or duct. Provision should be made for safe accessibility, ideally with an observation light and window.

Check that the construction of the duct wall is suitable enough to support the steam pipe for the duration of the installation life.


Dimension of hole size in the duct must be as per table below:

Steam manifold Ø	Hole size ØA
35mm	51mm
51mm	78mm

WARNING: Risk of condensing. Ensure that the minimum distance of the end of the manifold is at least 102mm from the top of the duct.



(Illus. 9)



Minimum distance (Illus. 10)

4.2.2. Recommendations for SAM distribution pipes


Model	Maximum Capacity	Outlet		Distribution pipes		Maximum static pressure					
	kg/hr	Qty	Diameter	Minimum length	Maximum length						
			mm	mm	mm	(Pa)					
SKE05	5	1	35	300	600	1245					
SKE10	10			600	1200						
SKE20	20										
SKE30	30	2	51	750	1500						
SKE40	40										
SKE50	50										
SKE60	60	3									
SKE80	80										

Note: For higher static pressure, please contact the manufacturer.




4.2.3. Placement of steam pipe in horizontal duct

35mm diameter pipe



51mm diameter pipe




Note: 51mm steam pipe must be supported on the end by appropriate duct hanger or strap (supplied by others).




4.2.4. Placement of steam pipe in vertical duct


Eyelet orientation



35mm diameter pipe




51mm diameter pipe





5. Steam output connection

5.1. Typical installation




(Illus. 21)

5.2. General recommendations

Please follow these general rules of installation in order to avoid any static pressure inside distribution pipes and into the humidifier evaporation chamber, and also to avoid any condensation accumulation.


- a) **The slope of the steam hose (rigid or flexible) should not be less than 15%** (7 horizontal length for 1 vertical length) in order to ensure continuous drainage of condensation back to humidifier or to steam trap.
- b) **Total length of the steam hose or rigid pipe should not exceed 5 meters.** Longer runs will result in added condensation losses. Whenever possible, use insulated copper piping. Flexible steam hose should be used for short runs (up to 5m) or for interconnecting between the rigid pipe runs.
- c) **Whenever using rigid copper, these ones should be insulated to diminish condensation build up.**




Incorrect installation
(Illus. 22)

5.3. Installation of "S" traps on the steam line

The lowest point of any steam hose or rigid pipe must be the humidifier. If necessary a steam separator (S trap) should be installed higher than the static pressure of the system by at least 51mm.



(Illus. 23)




(Illus. 24)





5.4. Position of steam output



Model	Dimensions mm			
Small Cabinet	I	J		
SKE05	110	122		



Medium Cabinet	K	L	M	
SKE10 SKE20	-	102	143	
SKE30 SKE40	134	102	143	



Large Cabinet	N	O	P	Q
SKE50 SKE60 SKE80	179	179	132	144



(Illus. 25)



5.5. Installation of humidifier with Space Distribution Unit (SDU)

- The SDU should be installed in an environment where the air is relatively clean. This will avoid the blower from getting clogged with dust.
- The humidifier should be mounted such that the SDU fan section is at least 2m above the floor.
- A minimum clearance of 0.45m from the ceiling should be allocated to avoid ceiling and wall condensation. If additional ventilation is not present, the fan should have a clearance from the ceiling of at least 1.35m. Proper ventilation must be observed to avoid ceiling and wall condensation.

SDU remote installation:


- The SDU can be in a different location from the humidifier (remote SDU). Please follow the piping recommendations (section 5.2).
- Mount the SDU to the wall on brackets (not supplied), do not drill mounting holes thru the cabinet of the SDU.
- Connect the steam hose(s) to the bottom inlet(s) of the SDU to the top of the steam outlet(s) of the humidifier. Secure the hose(s) with the supplied hose clamp.
- Connect the condensate hose to the bottom of the SDU to an open drain.
- Connect the electrical wires from the SDU to the top of the humidifier. Field wiring must conform to local codes.

The fan of the SDU will operate for a period of four minutes after steam production has stopped to prevent condensation.


Avoid any obstruction of the ventilation openings on top of the SDU.

Maintenance of the SDU:

- Clean the blower if there is an accumulation of dust.



SDU mounted on humidifier (Illus. 26)




SDU remote installation (Illus. 27)




6. Plumbing connection

The operation of SKE series humidifier is independent of variable water conditions, with soft or hard water. Therefore, for normal operation, no pre-treatment of water is necessary.



Bottom view (Illus. 28)

Model	Dimensions (mm)				
	A	B	C	D	E
SKE05	165	51	232	105	44
SKE10	184	44	248	105	44
SKE20					
SKE30					
SKE40					
SKE50	179	44	248	105	44
SKE60					
SKE80					




(Illus. 29)

6.1. Water supply

- Water inlet specifications:
 - ✓ Inlet water pressure: 0,7 to 4,8 bars (10 to 70 psig)
 - ✓ Maximum temperature: 30°C maximum
 - ✓ 3/8" standard copper water line connection
- A shut off valve (not supplied) should be installed in the water supply line to the unit, close to the humidifier to facilitate servicing.
- It is recommended to install a standard water strainer in the water supply line.

Please follow the steps described below:

- Connect 3/8" copper pipe to the bottom 3/8" compression fitting (supplied).
 - Finger tighten the swivel top 3/8" fitting to the male threaded part of the valve.
- CAUTION:** RISK OF DAMAGE TO THE VALVE. DO NOT USE WRENCH TO TIGHEN SWIVEL.



(Illus. 30)




6.2. Drain connection

- Drain connection specification:
 - ✓ Evaporation chamber water drain temperature: 60°C.
 - ✓ Standard hydraulic compression fittings: a ¾" (20mm) (evaporation chamber drain) and a ½" (15mm) (Pan drain).
- 2 hydraulic threaded fitting located under the humidifier (see Illus. 29) must be connected to the drain pipe.
- **Use standard copper hydraulic pipes ¾" (20mm) and ½" (15mm).**
- Ensure that the drain pipe dimension is sufficient, especially if more than one humidifier is evacuating into the same drain line.

7. Power supply connections


- **CAUTION:** RISK OF ELECTRIC CHOC. DISCONNECT THE HUMIDIFIER FROM THE ELECTRIC SUPPLY BEFORE TO PROCEED TO THE CONNECTION.
- **WARNING:** RISK OF FIRE. Do not interchange the power terminal block designated L1, L2 and L3 with Low voltage terminal block designated 1, 2 and 3.
- The wiring to the Humidifier should be done by a qualified electrician, and conforming to the procedure, regulation and local codes.
- Use only coppers conductors.
- An external over current protection and disconnect circuit breaker should be installed on the supply adjacent to the humidifier.
- A knock out (not supply) should be installed at the bottom of the electrical compartment of the humidifier for strain relief of the supply cable.
- Ensure that the size of the wire conductors is appropriate for the current supplied.
- Ensure that each terminal connection is properly secured.
- The ground conductor should be equipped with ring terminal and should be connected directly to the electrical panel on the indicated location.

1 Phase Connection



(Illus. 31)

3 Phases Connection




(Illus. 32)



8. Low voltage control connections

8.1. "ON/OFF" Humidifier




(Illus. 33)

8.2. Modulating Humidifier

8.2.1. Connection to the Humidifier control terminal block

Connection to HRO20 humidistat or HRO20 with remote humidity sensor (SHR10 or SHC80).




(Illus. 34)




8.2.2. Humidity control by humidifier (internal mode)

Humidity controlled by humidifier, using SHR10 or SHC80 as space sensor.



(Illus. 35)

VAV system with humidity controlled by humidifier, using SHC80 as Hi limit duct sensor and SHR10 or SHC80 as space sensor.




(Illus. 36)




8.2.3. Humidity Signals (internal mode)



Terminal Block





Modulating Printed Circuit Board



Humidity signal 2-10 Vdc






Humidity signal 4-20 mA






8.2.4. Control Signals

Terminal Block




Modulating Printed Circuit Board


Control signal 0-10 Vdc



Control signal 2-10 Vdc



Control signal 4-20 mA






8.3. Common Alarm Connections

A volt free contact is provided in the form of both a normally open and normally closed contact that will switch in the event of an alarm on the SKE humidifier.

- Wherever possible it is recommended to use the normally closed contact. This contact will open in the event of a humidifier fault.
- These contacts should be used to switch a low voltage, ideally **24V**, with a switching current of no more than **3 Amps**.



(Illus. 49)


8.4. Controls Placement (steam dispersed into a duct or AHU)

Typical humidifier control system should include along with the humidifier:

- A wall or return duct humidistat
- A high limit duct humidistat,
- An air proving switch.

Placement of these devices is critical to proper operation of the overall system.


- The return duct humidistat must always be located before any outside air intake, in order to ensure accurate sensing of the air from the humidified space.
- Alternatively a room humidistat can be used. The room humidistat should be located on an inside wall or column. It should not be near any discharge air from supply ducts or sources of heat or cold.
- The airflow switch must be positioned to accurately open on a loss of air flow, to prevent the humidifier from running when there is no air to absorb humidity.
- The high limit humidistat must be positioned far enough - 1.8m minimum - downstream of the steam dispersion manifold(s) to prevent it from getting wet, but still allows it to accurately prevent overhumidification of the duct that could result in condensation.



(Illus. 50)



9. Front panel display features






(Illus. 51)

Alphanumeric Display:

- 1 Indicates all operation parameters and the error messages (see section 14 – Trouble shooting).



Push button ,  and 

- 2

	M button: Used to access into program mode.
 	Up and Down button: Used to increase or decrease the controlled parameters of the humidifier.




"POWER" indicator

- 3

	The humidifier is powered by electricity and the switch is at the AUTO position.
	The humidifier is disconnected from the power supply.



"CHECK" indicator

- 4

	The "CHECK" indication is normally off. It will go on as a warning against abnormal conditions of operation. For details consult the Alphanumeric Display (see section 9.1.3 Diagnostic mode).
 <i>blinking</i>	Maintenance is required. The Running hours have exceeded the Service hours. (see section 12 – Service).
	No abnormal conditions of operation.




"FILL" indicator

- 5

	Indication that the water supply (fill) valve is open.
	Indication that the water supply (fill) valve is closed.

"STEAM" indicator

- 6

	ON/OFF model, the STEAM indicator lights when the contactor is closed and steam is being generated.
 <i>blinking</i>	Modulating model, the STEAM indicator blinks ON and OFF in proportion to the percentage of steam output the humidifier is generating. (The proportion is displayed on the alphanumeric display (1)). For 100% the indicator will be lit with no blink.
	There is no steam being produced.



Switch "AUTO/OFF/DRAIN"

- 7

AUTO	Position AUTO (I): Humidifier will generate steam based on demand from the humidistat.
OFF	Position OFF (O): Humidifier will shut off.
DRAIN	Position DRAIN: Humidifier will stop operating and the evaporation chamber will drain the water out. This will be done typically at regular service.

Indicator "DRAIN"

- 8

	Drain valve is opened, whether as a result of an automatic drain cycle or because the front panel switch is manually set to DRAIN.
	Drain valve is closed.



9.1. Description display modes

9.1.1. "OFF" Mode

When the rocker switch is in the "OFF" position, the display shows the model of the unit and the program version number.

NEP 3.3
SKE10M

(Illus. 52)

9.1.2. Scroll Mode

When the rocker switch is in the auto position, the display scrolls the following information every 6 seconds:

Display	Description	Comment
RH 25% DCT 68%	Display Space and Duct Relative Humidity readings.	Only on modulating humidifiers (suffix M). If no High limit Duct sensor is installed second line is left blank)
kg/hr 8	Quantity of steam produced by the humidifier	I.e.: The actual output of the unit at that moment is 8 kg/hr
ALARM LEVEL	Low water level.	Below this water level, the humidifier shuts off and the water supply valve is activated until sufficient level is reached.
CONTROL LEVEL	Water level is controlled	The water supply valve is activated below this level.
HIGH LEVEL	Water at maximum level.	The water supply valve is automatically deactivated



9.1.3. Diagnostic mode

When the following conditions occur, the diagnostic messages override the scrolling information:

<i>Display</i>	<i>Description</i>	<i>Comment</i>
NO DEMAND	No demand	Modulating humidifier: No analog signal to the humidifier. On/Off humidifier: Humidity level has exceeded the set point of the humidistat or humidity level has exceeded the set point on the high limit humidistat or airflow is not detected by the air pressure switch.
SAFETY OPEN	Safety open	Humidity level has exceeded the set point on the high limit humidistat or airflow is not detected by the air pressure switch (modulating humidifier only).
DRAIN CYCLE	Drain cycle	The humidifier is in the automatic drain mode.
CONTACT DELAY	Contact delay	15 second delay for the power contactor to be activated.
OVER HEATED	Overheated	The temperature inside the container has exceeded the boiling temperature. The humidifier has automatically shut off.
PROBE DEFECTED	Defected probe	The water level sensor is not operational. The humidifier has automatically shut off.
NO LEVEL	No water	Water has not reached the level probe
FOAMING CYCLE	Drain foam	AFEC (Anti Foam Energy Conservation) detects foam. The humidifier drains for a few minutes and returns to normal operation.
DRN/PROB BLOCK	Drain or probe block	The humidifier drains but the water level does not decrease, the humidifier has automatically shut off.
Verify RH Sens	Verify RH sensor	Signal from either HRM-X or HDM-X used as space sensor is lower than 0.49 Vdc to terminal # 6 of humidifier. There might be a connection problem or a defective sensor.
Verify DCT Sens	Verify Duct sensor	Signal from HDM-X used as Hi limit duct sensor is lower than 0.49 Vdc to terminal # 4 of humidifier. There might be a connection problem or a defective sensor.



9.2. Programming

To enter into programming mode, please push button at any time, to advance the program function to the next programming step in the menu push the same button twice.

Unless other instructions, you can make a selection by using & buttons on control panel.

Step	Display	Description	Comment
			To enable set point to humidifier display
			<ul style="list-style-type: none"> Press the button to reach step 5, the RUNNING message will appear. Press and hold the TEST button located on Main Pc board inside electrical compartment for 10 seconds. Release the TEST button then press the RESET button on the same main pc board. Set point is now displayed on the humidifier display.
01		Set point RH origin Out: Output set point to HRO20 or HDM. Int: Internal. Value : from 00 to 100% Default: Out 30%	If Output is selected, the set point is sent from the humidifier to the humidistat HRO20 or HDM. If HRM-X or HDM-X is connected with humidifier, please select Internal, this will allow you to set up RH set point directly from Humidifier. To switch between Output and Internal Set point: Press and hold the TEST button located on Main Pc board inside electrical compartment until the change of the value.
02 optional		Set point VAV allows Hi limit Duct humidity control OFF: Duct humidity control disable. 65%: High limit Duct humidity set point value. Default: OFF	If Set point VAV is disabling, no humidity signal from the VAV Duct will be considered. If a Set point VAV value is set, the humidity output will be controlled by both space and High limit duct humidity signal. To allow Set point VAV value: Press and hold the TEST button located on Main Pc board inside electrical compartment until OFF is disappeared. You can then select the VAV Set point value desired by using & buttons on control panel. <i>Note: This Step will appear only if Internal has been selected at step 01</i>
03 optional		Prop Band allows the set up of proportional band. From 3 to 9% Default: 3%	Proportional band can be set from 3% to 9% of the humidity set points values (Space and High limit duct). Select the appropriate value by using & buttons on control panel. <i>Note: This Step will appear only if Internal has been selected at step 01</i>
04		Drain frequency. From 1 to 24 hours Default: 4 Hrs	Choose the initiation of a drain cycle for 1 to 24 hours. In general, harder the water is, more often the drain cycle should be. Drain cycle setting does not affect the AFEC system.
05		Number of running hours Information only, no possible set up.	The humidifier has operated 645 hours since the last service. After service, press simultaneously & buttons for 15 seconds to reset the number of hours of operation to zero. This procedure will stop the CHECK indicator from flashing.
06		Hour span between servicing. From 400 to 1500 hours. Default: 1000 Hrs	You can set the number of hours of operation before the humidifier will call for service (blinking of CHECK light every 4 seconds) from 400 to 1500 hours. In general, harder the water is, lower the number of hours of operation before service should be.
07		Output Span. From 00 to 100%. Default: 100%	This option is available only on modulating model. i.e.: In this case, the humidifier will deliver 80% of its maximum rated output when at full demand.

Note: Any changes made in the Program Mode are saved into a non-volatile memory.

When the humidifier is anywhere in the Menu Driven Program Mode, the normal operation of the humidifier is halted.

To resume normal operation, exit the menu program mode by pressing the button until the alphanumeric display is clear. (This happens after step 7)




10. Control p.c. board

- The Printed circuit board designated "PCB970819" is common to all SKE series humidifier, ON/OFF or modulating, this pc board is equipped with an advanced microprocessor which controls all the humidifier functions.
- The Printed circuit board which is directly connected onto the main pc board is installed only on modulating model (suffix M).

10.1. Main p.c. board

- There are 3 water level L.E.D.'s in the upper right hand side. They indicate the relative water height as sensed by the water level sensor.
 - If HI is illuminated: water supply valve shuts off,
 - If LO is off: An evaporation chamber filling is ordered, water supply valve opens
 - If LA is off: No water is detected by the water level sensor, the power to the elements is shut off.
- The 3 status L.E.D.'s at the center left side operate as follows:
 - FILL indicates that the water supply valve is feeding water.
 - DRAIN indicates the drain valve empties the container.
 - CONT indicates that power is supplied to the elements and the unit is producing steam.
- TEST button should be used when commissioning the humidifier; this will initiate a preprogrammed start-up cycle. The start up cycle cleans the supply water and the evaporation chamber (see section 11 – start-up). This button enable also to display RH% measured by humidistat to humidifier display (see section 9.2 –Programming) (this is available only on Modulating model).
- RESET button enable the bypass of start up sequence.



(Illus. 53)

10.2. Modulating p.c. board

- The 3 jumpers at the center of the p.c. board (Control Input) are used for proper selection of the incoming control signal. See section 8.2.4 - Control signals.
- The 3 jumpers at the bottom of the p.c. board (Humidity Input) are used for proper selection of the incoming humidity signal. See section 8.2.3 – Humidity signals.



11. Start up procedure

We recommend to strictly following this start-up procedure in order to avoid any anomaly resulting from wrong cleaning of the components.

In case of problem or discrepancy see section 14 – Trouble shooting guide.

1. Make sure that mechanical, electric and plumbing connection are done and secured.
2. Make sure that low voltage control circuit is done and correct.
3. Turn on the water shut off valve (outside of the humidifier) and check that the drain connections are connected to the main drain line of sufficient diameter.
4. Turn on the power to the humidifier from the circuit breaker disconnect. The POWER indicator should go on.
5. Push the TEST button located on the main pc. Board. This pc. Board is located in the electrical compartment.
6. This will start up a pre-programmed start-up cycle. This start-up cycle will test functions of the humidifier and will flush out any dirt in the humidifier and supply lines.
This cycle will last about 1 hour.
Note:
 - a) the front panel rocker switch will not affect the performance of the start-up cycle.
 - b) In the case of modulating humidifier, there must be a demand signal of at least 50% for the start-up cycle to operate correctly.
 - c) To bypass at any time the start-up cycle and to proceed directly into normal operation, press the RESET button located on the main pc. board.
7. The front panel rocker switch may be left in the AUTO position during the start-up cycle. This will result in normal operation of the humidifier as soon as the start-up cycle is finished.
8. Your humidifier is now fully operational.



12. Service

12.1. General

- The humidifier is set to give service demand on the alphanumeric display and on the CHECK light after it has reached the service hours setting (see section 9.2- Programming)
- The routine service is a cleaning of the evaporation chamber.
- We recommend setting the service demand depending on the water quality, the frequency of automatic drain cycles and the demand placed on the humidifier.
- The manual cleaning frequency can be from every 2 months to once a year.

12.2. Evaporation chamber cleaning

WARNING: RISK OF BURN. THE EVAPORATION CHAMBER AND ITS CONTENT CAN BE EXTREMELY HOT, CHECK TEMPERATURE BEFORE HANDLING.

1. Cool down evaporation chamber

- Set the front panel switch "AUTO/OFF/DRAIN" to DRAIN. The humidifier will command a drain cycle.
- Ensure that the evaporation chamber is completely empty. When it is empty, set the front panel switch "AUTO/OFF/DRAIN" to AUTO, the evaporation chamber will be fill with cool water; the FILL light will be illuminated.
- As soon as the evaporation chamber is full of cool water, the FILL light will extinguish, Set the front panel switch "AUTO/OFF/DRAIN" to DRAIN again.
- At the end of this drain cycle, check the temperature of the evaporation chamber, to do so, open the front door of the humidifier and touch the evaporation chamber with the back of your hand, If it is cool enough you can go the sequence #2 if not repeat the cool down operation until it will be cool enough.
- Set the front panel switch "AUTO/OFF/DRAIN" to OFF

2. Shut down of the electrical supply

CAUTION: RISK OF ELECTRIC SHOCK. SHUT DOWN THE ELECTRIC SUPPLY OF THE HUMIDIFIER

- Turn off the main power supply to the humidifier.

3. Disconnection of heating element(s)

- Remove the high voltage connector located at the top right hand side of the mechanical compartment.
 - Model SKE05: Unscrew the connector.
 - Model SKE10 to SKE80: squeeze the locking ears of the high voltage connector and pull it apart.

4. Disconnection of the other accessories.

- Disconnect the connector from the water level sensor; this connector is attached to a cable that enters the mechanical compartment just below the high voltage connector. Squeeze the locking ear of the connector and pull it apart.
- Remove the connection to the high limit sensor (klixon), located on the top cover of the evaporation chamber.

5. Disconnection of steam hose and water pipe

- Remove the steam hose(s) at the top of the evaporation chamber.
- Remove the water drain/fill connection to the evaporation chamber. To do this, unscrew the nipple located on the lower right hand side of the evaporation chamber.

6. Removing the evaporation chamber

- The evaporation chamber may now be freely removed from the humidifier cabinet.
- **CAUTION:** The evaporation chamber still contains 1 inch of water, ensure that you do not reverse this water on yourself.
- Make sure that your footing is secure when lifting out the evaporation chamber. On large humidifier (SKE50 to SKE80) it may weigh more than 15 kg. This operation may require another person to assist you in removing the evaporation chamber.

7. Opening of the evaporation chamber

- Remove the cover from the evaporation chamber.
 - Model SKE05: Unlatch the 3 latches located around the evaporation chamber, *caution: these latches are very tight, we recommend you to help you with a screwdriver or pliers to do this.*
 - Model SKE10 to SKE80: Turn the latches of the 4 or 8 latches located around the evaporation chamber.
- Remove the cover from the evaporation chamber.



8. Cleaning of the evaporation chamber

- Pour out any remaining water and scale that is on the bottom of the container
- To clean out the remaining scale from the container, use a stiff brush (synthetic filament only) and some vinegar or any weak acid for cleaning stainless steel.
- **WARNING:** The use of wire brush or any non-recommended acid will void the warranty.
- If the amount of scale to remove is very important, the service demand frequency is too low for the quality of supply water, you should then adjust this service demand frequency (see section 9.2 – Programming). Too much scale may impair the normal operation of the humidifier or damage it; in this case warranty will be voided.

9. Cleaning of the other components


- The components installed on the cover (heating element and water level sensor) and the cover itself should be cleaned as necessary, only if some scale has been accumulated on them.
- Proceed as per the cleaning of the container (step #8).
- Removing and cleaning of the water level sensor.

A chamber protects the water level sensor. Cleaning of the sensor requires removing this chamber.

- Unscrew the 2 screws holding the chamber, located on the cover.
- Carefully remove the chamber, do not touch or damage the water level sensor.
- Clean out the water level sensor by using a clean soft cloth.

CAUTION: The water level sensor is covered by a thin lay of Teflon, any scratch or damage to this lay of Teflon may provoke failure of the humidifier.

- Clean or the chamber by proceeding as per the main container (see step #8).
- Re-attach the clean chamber to the cover and screw in the 2 screws on the top of the cover.






10. Re assembly of the evaporation chamber

- Rinse out the container and the cover with water.
- Check the cover gasket, and make sure that the gasket is well placed before to re-install the cover on the container. The water level sensor should be in front of the drain/fill connection of the evaporation chamber.
- Tighten the latches around the cover (3,4 or 6).
- Replace the evaporation chamber in the humidifier.
- Tighten the water drain/fill connection nipple.
- Replace the steam hose(s) on the outlet of the evaporation chamber.
- Reconnect the connector of the water level sensor, high temperature switch (klixon) and the high voltage connector of the heating element.

CAUTION: RISK OF FIRE. MAKE SURE THE HIGH VOLTAGE CONNECTOR IS PROPERLY LOCKED. AN UNPROPER CONNECTION MAY PROVOKE ELECTRIC ARCS.


11. Start-up of the humidifier

- Turn on the main power supply to the humidifier.
- The POWER light of the front panel should be illuminated.
- Press the  button to enter the programming mode, to reset the Running hours (see section 9.2- Programming Step 3).
- Set the front panel switch "AUTO/OFF/DRAIN" to AUTO. The humidifier will command to fill the evaporation chamber with water; the FILL light should be illuminated.
It is possible that the CHECK light will illuminate because the evaporation chamber is empty. This signal will extinguish as soon as the normal condition will be reach.
- If there is a humidity demand, the humidifier will produce steam again.



13. Exploded view & Bill of Material

13.1. Exploded view



(Illus. 55)



13.2. Bill of Material







Item	Description	Model	Part number
A	Container of evaporation chamber	SKE05	SW CONTSMA-ASSY
		SKE10 to SKE40	SW CONTMED-ASSY
		SKE50 to SKE80	SW CONTLAR-ASSY
B	Cover of evaporation chamber	SKE05 (1 phase)	SP 4018-M
		SKE05 (3 phases)	SP 4019-M
		SKE10 & SKE20	SP 4183A
		SKE30 & SKE40	SP 4183B
		SKE50 & SKE60	SP 4186
		SKE80	SP 4185A
C	Evaporation chamber gasket	SKE05	SP 1008
		SKE10 to SKE40	SP 1021
		SKE50 to SKE80	SP 1022
D	Heater element	See table below	
E	Level sensor chamber	SKE05	SP 4196-M
		SKE10 & 20	SP 4197-M
		SKE30/40/50/60/80	SP 4198-M
F	Washer (elements)	SKE05 to SKE80	SP 1005
G	S/S hex. Jam nut (elements)	SKE05 to SKE80	SP 2330
H	High temperature switch (klixon)	SKE05 to SKE80	SP 3035
I	Foam sensor	SKE05	SW FOAMSM-ASSY
		SKE10 to SKE40	SW FOAMMED-ASSY
		SKE50 to SKE80	SW FOAMLG-ASSY
J	Water level sensor	SKE05	SW PROBSM-ASSY
		SKE10 & 20	SW PROBMD-ASSY
		SKE30/40/50/60/80	SW PROBLAR-ASSY
K	Water supply valve	SKE05 to SKE80	SP 6003
			SP 6007 (IDC)
L	Fill and drain trap assembly	SKE05	SW TRAPSM-A-P
		SKE10 to SKE40	SW TRAPMED-P
		SKE50 to SKE80	SW TRAPLAR-P
M	Silicone tubing ½"	SKE05 to SKE80	SP 1023A
	Silicone tubing ¾"		SP 1023B
	PCV tubing ½"		SP 1027
N	Alphanumeric display	SKE05 to SKE80	SW SK300DISPLAY
O	"AUTO/OFF/DRAIN" rocker switch	SKE05 to SKE80	SP 3037
P	Terminal block and high voltage connectors	SKE05 to SKE80	/
Q	Cooling fan	SKE05 to SKE80	SP 3007
R	Transformer	See table below	
S	Contactor	See table below	
T	Solid State Relay	50 A	SP 3102
		90 A	SP 3103
		125 A	SP 3105
U	Main Printed circuit board	SKE05 to SKE80	NW SKEMAIN-TEST
V	Modulating Printed circuit board	SKE05 to SKE80	NW SK300MODULSS
W	SDU fan	SDU I	SW FANSDU1-RET
		SDU II	SW FANSDU2-RET
		SDU III	SP 3010
X	Transformer	See table below	
Y	Fuse inside SDU	SDU I and SDU 2	SP 5105
		SDU 3	SP 5106
Z	Drain pump	SKE05 to SKE80	SP G4101



Item	SKE05		SKE10		SKE20	SKE30	SKE40	SKE50	SKE60	SKE80
	230V/1~	400V/3~	230V/1~	400V/3~	400V/3~	400V/3~	400V/3~	400V/3~	400V/3~	400V/3~
D Heater element	SE 5937	SE 5980	SE 5983	SE 5981	SE 5982	SE 5983	SE 5955	SE 5984	SE 5983	SE 5955
R Transformer	SP 3365	SP 3374	SP 3365	SP 3374	SP 3374				SP 3374	
S Contactor	SP 3080	SP 3080	SP 3083	SP 3080	SP 3100	SP 3100	SP 3084	SP 3084	SP 3100	SP 3084
X SDU Transformer	SP 3373	SP 3373	SP 3371	SP 3376		SP 3370		-	-	-



14. Trouble shouting guide

Problem	Indicator	Display	Causes	Corrective actions
Humidifier does not operate (Power Off)	Power: Off		<ul style="list-style-type: none"> The humidifier is not powered. The low voltage fuse is open. The high temperature switch is open. Wires harnesses inside the humidifier are not secured properly. 	<ul style="list-style-type: none"> Check for the main power supply and fuses. Check the transformer, the low voltage fuse. Check the high temperature switch, the wires harnesses and the Main pc board.
	Check: Off			
	Fill: Off			
	Steam: Off			
	Drain: Off			
Humidifier does not operate (Power On)	Power: On		<ul style="list-style-type: none"> The rocker switch is at the OFF position. Wire harness from the LED display panel to the Main pc board is not secured properly. 	<ul style="list-style-type: none"> Press the rocker switch to the AUTO position. Check the white color wire harness. Press the RESET button on the Main pc board.
	Check: Off			
	Fill: Off			
	Steam: Off			
	Drain: Off			
Humidifier does not produce steam (No Demand)	Power: On		<ul style="list-style-type: none"> Modulating humidifier: no analog signal. On/Off humidifier: no demand from humidistat or air flow is not detected by air pressure switch or high limit humidistat is open. Control wires are not properly secured to the terminal blocks. 	<ul style="list-style-type: none"> Verify the setting of the humidistat. Check the fan operation. Check the operation of the high limit humidistat. Verify the connections of the wires to the control terminal blocks.
	Check: Off			
	Fill: Off			
	Steam: Off			
	Drain: Off			
Humidifier does not produce steam (Safety Open) Modulating humidifiers only	Power: On		<ul style="list-style-type: none"> Air flow is not detected by air pressure switch or high limit humidistat is open. Control wires are not properly secured to the terminal blocks. 	<ul style="list-style-type: none"> Check the fan operation. Check the operation of the high limit humidistat. Verify the wires to the control terminal blocks #1 & 2.
	Check: Off			
	Fill: Off			
	Steam: Off			
	Drain: Off			
No water inside the evaporation chamber Or Humidifier will not stop draining	Power: On		<ul style="list-style-type: none"> Humidifier is filling with water and has not reached or is not reaching the high of the water level sensor. Humidifier is not filling with water. 	<ul style="list-style-type: none"> Verify if the drain valve is manually open. Check if the shut off valve on the water supply line is open. Verify the operation of the fill valve. Check the fill valve strainer and the external strainer are not blocked.
	Check: On			
	Fill: On			
	Steam: Off			
	Drain: Off			
Humidifier is always on Foam cycle	Power: On		<ul style="list-style-type: none"> Excessive foaming condition inside the evaporation chamber. Foaming sensor is grounded. 	<ul style="list-style-type: none"> Verify the quality of the supply water. Verify if chemical products were used to clean the evaporation chamber during maintenance. Rinse with water the chamber properly. Check the setting of the Drain cycle. Reduce the time between Drain cycles.
	Check: Off			
	Fill: On			
	Steam: Off			
	Drain: On			



Problem	Indicator	Display	Causes	Corrective actions
Humidifier is operating and the CHECK light is blinking	Power: On	<div>SCROLL MODE</div>	<ul style="list-style-type: none"> The Running hours have exceeded the Service hours. 	<ul style="list-style-type: none"> Service the evaporation chamber, see section 14. Reset the Running hours to cancel the blinking of the CHECK light, see section 9.2 STEP 3.
	Check: Blink			
	Fill: Off			
	Steam: On			
	Drain: Off			
Humidifier is not operating and the CHECK light is ON	Power: On	<div>OVER HEATED</div>	<ul style="list-style-type: none"> The electronic temperature sensor inside the water level sensor had sensed abnormal temperature. The quick connector to the water level sensor was removed while the humidifier was operating. The brown wire connected to the top left corner of the Main pc board is not properly secured. 	<ul style="list-style-type: none"> Verify if the humidifier was operating below the standard water level then replace the item J. If connector was removed while powered was still ON then press on the main pc board the TEST button until the Drain light is ON then press RESET once. Verify the connection of the brown wire to the Main pc board.
	Check: On			
	Fill: Off			
	Steam: Off			
	Drain: Off			
Humidifier is not operating and the CHECK light is ON	Power: On	<div>PROBE DEFECTED</div>	<ul style="list-style-type: none"> The water level sensor is damaged. 	<ul style="list-style-type: none"> Replace the water level sensor, item J.
	Check: On			
	Fill: Off			
	Steam: Off			
	Drain: Off			
Humidifier will not drain	Power: On	<div>DRN/PROB BLOCK</div>	<ul style="list-style-type: none"> During a Drain or Foaming cycle, the water level sensor has sensed the water level has not decreased. 	<ul style="list-style-type: none"> Verify the drain valve, the fill and drain water pipe connection, the water level sensor chamber are not obstructed.
	Check: On			
	Fill: Off			
	Steam: Off			
	Drain: Off			
Humidifier does not operate and display is blank	Power: On	<div></div>	<ul style="list-style-type: none"> The following components can be the cause of this problem: water level sensor (item J), main pc board (item U), modulating pc board (item V) or the LCD display (item N). 	<ul style="list-style-type: none"> Call factory for trouble shooting instruction.
	Check: Off			
	Fill: Off			
	Steam: Off			
	Drain: Off			
Humidifier is producing steam and display is blank	Power: On	<div></div>	<ul style="list-style-type: none"> The potentiometer contrast is set at the lowest setting. The display ribbon cable is not connected properly. The LCD display is defective. 	<ul style="list-style-type: none"> Adjust the contrast of the display. Verify the connections of the ribbon cable are properly secured and on the right side (red line on cable). Replace the LCD display, item N.
	Check: Off			
	Fill: Off			
	Steam: On			
	Drain: Off			



Personal notes



Personal notes



1. General

Unless otherwise arranged, in writing, the acceptance of the Order Confirmation by the purchaser includes acceptance of the "General Conditions of Sale and Warranty" of National Environmental Products, Ltd hereafter referred to as NEP.

2. Incoterms

The international rules for interpretation of trade terms "Incoterms" as defined by the ICC Incoterms publication no. 460 from 1990, shall apply to the commercial terms used herein.

3. Confirmation of Order

- NEP shall not be deemed to have accepted an order until written "**Order Confirmation**" from NEP is issued to the purchaser.
- It is the responsibility of the purchaser to verify that all information concerning his/her order is correct and to notify NEP in writing, of any discrepancy prior to the order being shipped. In the event of a change or correction to an existing order, a second "Order Confirmation" will be issued by NEP.

4. Price

- Our prices are net, Ex-works Montreal in U.S. Currency, unless stated otherwise.
- Minimum orders shall be \$50.00 minimum.
- Shipping and Handling charges are \$5.00 minimum per order unless the shipment is billed to the purchaser's account or shipped freight collect.
- NEP reserves the right to adjust accepted prices in the event of alterations in rates of exchange, variations in costs of materials, changes in wages, interference on the part of the Government or similar conditions over which NEP has no control.

5. Payments terms

- Major credit cards, C.O.D., Prepayment.
- For open account, invoices are payable within 30 days from the date of invoice without no deduction, unless specify otherwise.
- An interest charge of 2% per month will be included on all overdue payments.
- No new order will be process if invoices are not paid within 45 days.

6. Transfer of ownership

The goods shall remain the property of NEP until the full payment for the goods has been received by NEP.

7. Delivery terms

- Shipments are Ex-works **400 Lebeau, St Laurent, Quebec, H4N 1R6, CANADA** unless notified otherwise.
- Unless special instructions, the order will be delivery in the way which NEP deems best without guaranteeing this to be the cheapest way of transport.
- For International Order, a written designation naming the freight forwarding agent is required and will remain in effect until notified otherwise.
- Any discrepancy, damage or breakage should be reported in writing both to NEP and to the Carrier within 5 working days from the receipt date.

8. Risk

From the moment of delivery, the purchaser shall bear all risks for the goods and NEP shall not be responsible for loss and damage incurred during transportation.

9. Delivery time

- Delivery time is stated approximately and depends on the product ordered, please allow a minimum of:
 - a) 2 weeks for processing North American order.
 - b) 6 weeks for processing International order.
- We will make every effort to adhere to our delivery promises, but will not accept order or contract cancellation or any liability for any direct or indirect losses that may arise for any reason whatsoever as a result of our failure to adhere to such promises.

10. Return of good

- Goods received by the purchaser cannot be returned unless a completed "**R.M.A. Form**" (Return Material Authorization Form) has been issued by NEP's **Customer Service**.
- Any returned goods must be sent to NEP 400 Lebeau, St Laurent, Quebec, H4N 1R6, CANADA, unless stated otherwise by the R.M.A. Form, accompanied with the completed "R.M.A. Form", the **R.M.A. number** shall be prominently displayed on the shipping box. Unauthorized returns will be refused.
- Any returned goods must be sent freight prepaid. Any goods that come to us freight collect will be refused and returned to sender unless previously agreed to by us in writing on the "R.M.A. Form".
- Goods returned for credit shall be in condition for resale in the original box and properly packaged. Units, accessories or components that have been installed are not returnable and not refundable. Credit is subject to an overhead charge of 30% of the invoice plus shipping & handling if returned within 30 days of the invoice date and 50% from 30 to 60 days.
- Non standard product (SK units with special feature), Multisteam manifolds and any DI unit are not returnable and not refundable.

11. Warranty

- Provided that the terms of payment are observed, the purchaser is offered a warranty of **24 months** from the original purchase date of delivery for any NEP's **standard product**, provided the equipment has been properly installed and operated in accordance with NEP instructions.
- The warranty covers faulty manufacture, design and/or defective materials. The warranty shall cease to be valid in the event of misapplication, incorrect installation, **improper maintenance** or any other incorrect uses or misuse of the product.
- For the SK series, the warranty furthermore ceases to be valid if the user disconnects or removes any electronic or mechanical components prior disconnecting the input power. NEP assumes no responsibility for repairs made on equipment, unless performed by NEP's authorized personnel.
- The defective product or component shall be returned in accordance with the paragraph 10 (Returns of goods) as described in this document.
- NEP agrees under the warranty to repair or replace (at the discretion of NEP) such standard product or component, which upon examination by NEP are found to be defective.
- Product or component replaced or repaired under warranty will be sent back to the purchaser, standard freight paid by NEP
- Expenses in connection with travelling time, dismantling and mounting shall not be paid by NEP
- Guarantee for products or components sold but not manufactured by NEP, is only given to the same extent as given to NEP, however, not exceeding the normal NEP warranty.
- Parts used for repairs are warranted for the balance of the term of the warranty on the original humidifier or 90 days, whichever is longer.
- Any repair made, after the original warranty period, at the NEP facilities are warranted for 1 month from the date of repair.

12. Proper law and jurisdiction

This contract is and shall be deemed to have been made in the province of Quebec, CANADA, and shall in all respects, be governed by the province of Quebec laws.